



## 40d120 Translation Order Guide #1

### Primary Directory Number Configuration – Tone Commander 40d Console

1. Customer Name:	
2. Customer Contact:	
3. Service Address:	
4. Billing Telephone #:	
5. Area Code (NPA):	
6. Directory Number (DN):	
7. Long Distance Carrier (PIC):	
8. Maximum B Channels (BCHDN):	1
9. Bearer Capability	
BCDN:	SP & AU3
BCHCT:	2-VI & 0-CMD & 0-PMD
IBCHCT:	2-VI & 0-CMD & 0-PMD
OBCHCT:	2-VI & 0-CMD & 0-PMD
CT:	VI
10. Terminal Limit (TERMLIM):	1
Other Associated Terminal DN:	None
11. Terminal Class of Service (TSPCOS):	ICHD & NOTIFY & EKTS & CACH & BRGCE & DN3PBRG
12. Centrex Class of Service (CXSCOS):	CT
13. Feature Activators (FA):	58-DPN 60-TWC 62-DLPA 55-CALLPARK 56-CALLRTRV
Feature Indicators (FI):	58-DPN 60-TWC 55-CALLPARK 56-CALLRTRV

### Customer Group Configuration

14. Customer Group Number (CSTMGRP):	
15. Customer Group Type (TYPE):	EKTS
16. EKTS Timer Value (EKTST1):	18

### Directory Number Configuration

17. Call Type (CT):	VI
18. Class of Service (COS):	EKTS & ICND & NOICCNTN & RND
19. Call Diversion (DIV):	CFV & UPCFVDN & NOCFIND & NORRNG & CCNOAREQ
20. Category (CAT):	EKTS
21. Customer Group Number (CSTMGRP):	<i>reference Customer Group Number in item 14 above</i>
22. Traffic Restrictions (TRARSTR):	CARDT7 & CARDT8

### Directory Number Call Appearance Assignments

Directory Number (DN)	Call Appearance Assignment (DNCA)	Features (FA/FI)	Call Forward Authorize (AUTH)	Alerting Pattern (ALERTPAT)
23.	1-1 & 2-2 & 3-3 & 4-4 & 5-5 & 6-6 & 7-7 & 8-8	57-CFV	UPCFVDN	NORMAL
24.				
25.				
26.				
27.				

# Tone Commander 40d120 Installation Instructions

Siemens  
National ISDN

## 40d120 Translation Order Guide #2

### Primary Directory Number Configuration – Tone Commander 120d Console, DSS Keys 1-60

1. Customer Name:	
2. Customer Contact:	
3. Service Address:	
4. Billing Telephone #:	
5. Area Code (NPA):	
6. Directory Number (DN):	
7. Long Distance Carrier (PIC):	
8. Maximum B Channels (BCHDN):	1
9. Bearer Capability	
BCDN:	SP & AU3
BCHCT:	1-VI & 0-CMD & 0-PMD
IBCHCT:	1-VI & 0-CMD & 0-PMD
OBCHCT:	1-VI & 0-CMD & 0-PMD
CT:	VI
10. Terminal Limit (TERMLIM):	2
Other Associated Terminal DN:	
11. Terminal Class of Service (TSPCOS):	ICHD & NOTIFY & EKTS & CACH & BRGCE
12. Centrex Class of Service (CXSCOS):	
13. Feature Activators (FA):	
Feature Indicators (FI):	

### Customer Group Configuration

14. Customer Group Number (CSTMGRP):	
15. Customer Group Type (TYPE):	EKTS
16. EKTS Timer Value (EKTST1):	18

### Directory Number Configuration

17. Call Type (CT):	VI
18. Category (CAT):	EKTS
19. Class of Service (COS):	EKTS & ICND & NOICCNTN & RND
20. Call Diversion (DIV):	
21. Customer Group Number (CSTMGRP):	<i>reference Customer Group Number in item 14 above</i>

### Directory Number Call Appearance Assignments

See the 40d120 Translation Order Guide #3.



**40d120 Translation Order Guide #3**

Shared Call Appearance Assignments – Tone Commander 120d Console, DSS Keys 1-60

**PDN for DSS keys 1-60:** \_\_\_\_\_

DSS Key	Directory Number	DNCA	Alerting Pattern
1		1-1	NORMAL
2		2-1	NORMAL
3		3-1	NORMAL
4		4-1	NORMAL
5		5-1	NORMAL
6		6-1	NORMAL
7		7-1	NORMAL
8		8-1	NORMAL
9		9-1	NORMAL
10		10-1	NORMAL
11		11-1	NORMAL
12		12-1	NORMAL
13		13-1	NORMAL
14		14-1	NORMAL
15		15-1	NORMAL
16		16-1	NORMAL
17		17-1	NORMAL
18		18-1	NORMAL
19		19-1	NORMAL
20		20-1	NORMAL
21		21-1	NORMAL
22		22-1	NORMAL
23		23-1	NORMAL
24		24-1	NORMAL
25		25-1	NORMAL
26		26-1	NORMAL
27		27-1	NORMAL
28		28-1	NORMAL
29		29-1	NORMAL
30		30-1	NORMAL

DSS Key	Directory Number	DNCA	Alerting Pattern
31		31-1	NORMAL
32		32-1	NORMAL
33		33-1	NORMAL
34		34-1	NORMAL
35		35-1	NORMAL
36		36-1	NORMAL
37		37-1	NORMAL
38		38-1	NORMAL
39		39-1	NORMAL
40		40-1	NORMAL
41		41-1	NORMAL
42		42-1	NORMAL
43		43-1	NORMAL
44		44-1	NORMAL
45		45-1	NORMAL
46		46-1	NORMAL
47		47-1	NORMAL
48		48-1	NORMAL
49		49-1	NORMAL
50		50-1	NORMAL
51		51-1	NORMAL
52		52-1	NORMAL
53		53-1	NORMAL
54		54-1	NORMAL
55		55-1	NORMAL
56		56-1	NORMAL
57		57-1	NORMAL
58		58-1	NORMAL
59		59-1	NORMAL
60		60-1	NORMAL

# Tone Commander 40d120 Installation Instructions

**Siemens**  
**National ISDN**

## 40d120 Translation Order Guide #4

### Primary Directory Number Configuration – Tone Commander 120d Console, DSS Keys 61-120

1. Customer Name:	
2. Customer Contact:	
3. Service Address:	
4. Billing Telephone #:	
5. Area Code (NPA):	
6. Directory Number (DN):	
7. Long Distance Carrier (PIC):	
8. Maximum B Channels (BCHDN):	1
9. Bearer Capability	
BCDN:	SP & AU3
BCHCT:	1-VI & 0-CMD & 0-PMD
IBCHCT:	1-VI & 0-CMD & 0-PMD
OBCHCT:	1-VI & 0-CMD & 0-PMD
CT:	VI
10. Terminal Limit (TERMLIM):	2
Other Associated Terminal DN:	
11. Terminal Class of Service (TSPCOS):	ICHD & NOTIFY & EKTS & CACH & BRGCE
12. Centrex Class of Service (CXSCOS):	
13. Feature Activators (FA):	
Feature Indicators (FI):	

### Customer Group Configuration

14. Customer Group Number (CSTMGRP):	
15. Customer Group Type (TYPE):	EKTS
16. EKTS Timer Value (EKTST1):	18

### Directory Number Configuration

17. Call Type (CT):	VI
18. Category (CAT):	EKTS
19. Class of Service (COS):	EKTS & ICND & NOICCNTN & RND
20. Call Diversion (DIV):	

### Directory Number Call Appearance Assignments

See the 40d120 Translation Order Guide #5.



**40d120 Translation Order Guide #5**

Shared Call Appearance Assignments – Tone Commander 120d Console, DSS Keys 61-120

**PDN for DSS keys 61-120:** \_\_\_\_\_

DSS Key	Directory Number	DNCA	Alerting Pattern
61		1-1	NORMAL
62		2-1	NORMAL
63		3-1	NORMAL
64		4-1	NORMAL
65		5-1	NORMAL
66		6-1	NORMAL
67		7-1	NORMAL
68		8-1	NORMAL
69		9-1	NORMAL
70		10-1	NORMAL
71		11-1	NORMAL
72		12-1	NORMAL
73		13-1	NORMAL
74		14-1	NORMAL
75		15-1	NORMAL
76		16-1	NORMAL
77		17-1	NORMAL
78		18-1	NORMAL
79		19-1	NORMAL
80		20-1	NORMAL
81		21-1	NORMAL
82		22-1	NORMAL
83		23-1	NORMAL
84		24-1	NORMAL
85		25-1	NORMAL
86		26-1	NORMAL
87		27-1	NORMAL
88		28-1	NORMAL
89		29-1	NORMAL
90		30-1	NORMAL

DSS Key	Directory Number	DNCA	Alerting Pattern
91		31-1	NORMAL
92		32-1	NORMAL
93		33-1	NORMAL
94		34-1	NORMAL
95		35-1	NORMAL
96		36-1	NORMAL
97		37-1	NORMAL
98		38-1	NORMAL
99		39-1	NORMAL
100		40-1	NORMAL
101		41-1	NORMAL
102		42-1	NORMAL
103		43-1	NORMAL
104		44-1	NORMAL
105		45-1	NORMAL
106		46-1	NORMAL
107		47-1	NORMAL
108		48-1	NORMAL
109		49-1	NORMAL
110		50-1	NORMAL
111		51-1	NORMAL
112		52-1	NORMAL
113		53-1	NORMAL
114		54-1	NORMAL
115		55-1	NORMAL
116		56-1	NORMAL
117		57-1	NORMAL
118		58-1	NORMAL
119		59-1	NORMAL
120		60-1	NORMAL